

Main Menu

FPS

- Basic: 8 – 60 fps
24 fps
- Advanced: 1 – 60 fps
23.976 fps

dependent on Resolution & REDCODE settings

ISO

- 250 – 12800
ISO 800

F-Stop

- Available with RED Canon EOS Mount
- Basic: Allows adjustment of the aperture, range depends on attached lens
- Advanced: Aperture Enter F-stop directly
- Focus Enter focal distance directly, range depends on attached lens

1/SEC (Exposure)

- Basic: 1 sec – 1/8000 sec
1/48 sec
 - Advanced: Exposure (Speed) 1 – 1/8000 sec
1/48 sec
 - Integration Time 0.125 – 1000 ms
20.833 ms
 - Angle* -1.000 – 360.000 deg
Absolute Angle 180.000 deg
- * “Relative“ or „Absolute“ dependent on shutter mode

White Balance

- Basic: 1700 – 10000 K
 - Advanced:
 - Preset Daylight
 - Incandescent (2800K)
 - Tungsten (3200K)
 - Flourescent (4500K)
 - Flash (5500K)
 - Daylight (5600K)
 - Cloudy (7500K)
 - Shade (9000K)
 - Color Temp. 1700 – 10000K
5600 K
 - Tint -100.000 – 100.000
0
 - Calc White Balance
- Apply Preset

Resolution

- 5K
- 4K HD
- 4K
- 4K HD
- 3K
- 2K

REDCODE

- 3:1 – 18:1
8:1
- dependent on Resolution & fps



RED SCARLET MENU GUIDE



Menu Guide OCTAMAS AG Switzerland
mail@octamas.com +41 44 401 58 00
www.octamas.com


LEGEND

- ◁ Lorem ipsum Are default values
- ▶ Playback
- Exit Playback
- Touch this menu icon to enter the Secondary Menus / to return to settings menu
- Touch and hold to lock the touchscreen
- Advanced Touch and hold or double-click on an icon to bring up an advanced interface display
- Keypad for entering information directly
- Keyboard for entering information directly
- Slider to adjust levels
- Touch and hold to unlock the touchscreen

Secondary Menus 1/8





RED SCARLET MENU GUIDE




Exposure

Not Implemented at this time



Settings


Settings see next pages



Secondary Menus 2/8

Settings

Display




RED SCARLET MENU GUIDE



Menu Guide OCTAMAS AG Switzerland
 mail@octamas.com +41 44 401 58 00
 www.octamas.com

Settings

Display




RED SCARLET MENU GUIDE


Secondary Menus 4/8

Settings

Look



Project




RED SCARLET MENU GUIDE



Settings

Audio/Video



**RED SCARLET
MENU GUIDE**

Secondary Menus 6/8


Settings

Audio / Video



Automatically assign menu screen if enabled
unchecked

- Turning monitors ON/OFF or changing resolution requires a restart
- HDSDI and HDMI cannot be enabled at the same time
- Double-tapping on the touch LCD will re-enable the menus
- Settings will be applied when the dialog is closed




**RED SCARLET
MENU GUIDE**

 **OCTAMAS**

Menu Guide **OCTAMAS AG Switzerland**
mail@octamas.com +41 44 401 58 00
www.octamas.com

Secondary Menus 7/8

Settings Setup



Secondary Menus 8/8




RED SCARLET MENU GUIDE

Settings

Maintenance

Playback



Allows you to view clips and also allows you to change the look of the playback clips, see operation guide p. 132 - 140

LEGEND

- ▶ Playback
- Exit Playback
- x1 Playback Speed
- ⋮/▬ In Point Marker
- ◀ Frame-by-frame reverse
- ▶ / || Play / Pause
- ▶ Frame-by-frame forward
- ▬/⋮ Out Point Marker
- / ↻ Play once / Loop
- / ← Playback direction

